



# #2164 -2-1SS Trapeze Kit

## Assembly Instructions

BEFORE ASSEMBLY, review the detailed diagram to familiarize yourself with each part.

### Step-by-Step Instructions for assembling kit.

1. Thread 6 nuts and 6 washers onto both pieces of all thread, alternating the washer position first below then above the nut until all six nuts & washers are on the all thread. Repeat for both pieces of all thread.
2. Insert the slot of the angle over the all thread between the nuts and washers. Hand tighten.
3. Measure the distance from the bottom of one side of the all thread to the bottom of the angle and compare to the other side. Adjust nuts until the angle is even.
4. Repeat until all three runs of angle are attached to the all thread.
5. Tighten the nuts.
6. Install on ice bridge per contractor design using fender washers and nuts provided. See illustration below.

